



Installation Instruction with applicator and tips for:

iPhone 7 / 8

iPhone 7+ / 8+

iPhone 6 / 6s

iPhone 6+ / 6s+

Under the following link you can watch the installation video for the screen protector 2.0 4D—>

<https://youtu.be/70cPff1CeoU>

Step 1

Unpack the GLAZ screen protector and the attachments.

Now use the alcohol cloth to clean your iPhone. Grate thoroughly over the front and the edges. **Please note in particular to clean brand new equipment very thoroughly.** Then use the microfibre cloth to clean your display.

Take off one of the stickers and go over the display with the adhesive side.

Repeat this step until the display is clear of any dust. Now make sure that you don't touch the screen with your fingers!



Step 2

Place the applicator with the button holes down and push down until it is firmly seated on the unibody. You can see from the top now the elevations at the corners. These are used for the exact installation of the screen protector. Check again if the display is dust-free.



Step 3

Now pull the screen protector off the plastic card.

Step 4

Now put the screen protector in the applicator. **Please note the different procedures for the iPhone 6 / 6s / 7/8 and for the Plus models**

Procedure for the iPhone 6 / 6s / 7/8:

Orient yourself by the earpiece so that it can be seen correctly in the recess of the screen protector. Then put on the screen protector and press it lightly down the bottom of the home button in the corners.



For iPhone 6 Plus / 6s Plus / 7 Plus / 8 Plus:

Since there may be large manufacturing tolerances in the Plus models even within a model range, it may happen that your screen protector in the applicator has a little play.

In this case, align the screen protector very carefully at the bottom of the home button, so that the whole homebutton recess sits perfectly in the center. Check the position of the screen protector on the earpiece, and then press it. If you are not satisfied with the position of the screen protector, you can easily lift it and correct it in the applicator.



Step 5

If the screen protector fits perfectly, you can now gently press it in the corners. Now carefully remove the applicator. This sits tight and could lift the screen protector.

Step 6

Wait a while and watch the screen protector tighten on its own.

Step 7

Now use the small plastic tile or the fingernail to push the last trapped air from the center to the edge of the display. Apply light pressure to the display and push the bubbles to the edge.



Step 8

For smaller air inclusions, rub the microfibre cloth from the inside to the outside in a circular motion to remove it. Occasionally, bubbles may still be present under the GLAZ screen protector. The acrylic coating ensures that the screen protector tightens. Generally, the bubbles disappear within 24 hours.

What can you do if the bubbles do not disappear?


It is absolutely natural for us that after a certain wait your screen protector must be perfectly and bubble free on your iPhone !!

If the bubbles under your screen protector have not disappeared after 24 hours, you can edit them with the 2 times folded microfibre cloth and a ballpoint pen with light pressure and circular motions.

If the bubbles are persistent, you can heat the appropriate places with a hair dryer and then work again as described above.

Unfortunately, bubbles can be very persistent in some cases. We ask you to wait a few days in such cases. In 99% of the cases, the remaining bubbles just disappear as if by magic.

And if there is still a bubble, then please contact us by mail or call us. We will help you immediately.



A little tip at the end:

The Touch ID Button consists of a ring and a foil. You can either use them together, or loosen the ring from the foil and apply it one by one.

The fingerprint sensor is not affected by the Touch ID button.

If your fingerprint sensor still does not respond properly, please update it with the carrier foil or use only the ring.